

# NAMUOS

## ASSEMBLY & INSTALLATION GUIDE

### Adhesive Wall Hook

FOUR SIMPLE STEPS TO A SECURE, LASTING HOLD

---

1

#### CHOOSE THE RIGHT SURFACE

This adhesive works best on smooth, non-porous surfaces such as ceramic tile, glass, metal, finished wood, or smooth plastics. Avoid drywall, wallpaper, painted walls, or textured tiles.

---

2

#### CLEAN THE SURFACE

Clean the exact mounting area with rubbing alcohol (isopropyl alcohol). Do not use household glass cleaners or soapy water — they leave behind a microplastic film that prevents the tape from bonding.

---

3

#### MOUNT TO THE WALL

Remove the remaining red protective liner from the tape. Carefully align the holder, then press it firmly against the wall with heavy, even pressure for at least 30 seconds.

---

4

#### WAIT BEFORE USE

Do not hang any weight immediately.

Minimum wait time: 24 hours · Ideal wait time: 72 hours

**Thank you for choosing NAMUOS**

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE