

# NAMUOS

A S S E M B L Y & I N S T A L L A T I O N G U I D E

## Concrete Wall Hook

T H R E E S I M P L E S T E P S T O A S E C U R E M O U N T

---

1

### DRILL THE HOLE

Make sure you drill straight into the wall at a 90° angle.

---

2

### INSERT THE WALL PLUG & SCREW

Insert the wall plug into the hole, then install the screw. Ensure the screw is installed to the correct depth, leaving **10 mm** of the screw protruding from the wall.

---

3

### SECURE THE SCREW

Secure the screw to the wall using a nut (for an M4 screw).

- **Do not overtighten the screw.**
- **Incorrect installation depth may result in product damage.**

**Thank you for choosing NAMUOS**

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE